








LCD1770NX(A)



Four Direction Control Knob Control Buttons Soft Power SW Power LED



Cable Management Recess USB Downstream Connector (2 channel)

